


APPLY TACK ON
GRINDED PAVEMENT
SURFACE. SURFACE
COURSE SHALL BE PG
64-16 ARHM-GG-C, OR
AS APPROVED.



SAWCUT EXISTING
PAVEMENT AND APPLY
HEAVY ASPHALTIC TACK
COAT ON SAWCUT FACE.

FILL POTHOLE OR
CORE FLUSH TO
EXISTING PAVEMENT
WITH ONE AND
ONE-HALF SACK (MIN)
CEMENT SLURRY
BACKFILL.

NOTE:

- 1.) SEE TRENCH BACKFILL AND ROADWAY REPAIR NOTES STD No MVSI-132C.
2. WHEN MULTIPLE POTHOLES SPACED 24" OR LESS ARE RUN PARALLEL TO THE TRAFFIC LANE, STANDARD PLAN MVSI-132B SHALL BE USED.

NOT TO SCALE



RECOMMENDED:
MDL 10/13/20
DIVISION MANAGER DATE
APPROVED:
MLW 10/24/20
PUBLIC WORKS DIRECTOR DATE
CITY ENGINEER

CITY OF MORENO VALLEY
PUBLIC WORKS DEPARTMENT - CAPITAL PROJECTS DIVISION

**UTILITY POTHOLE OR
PAVEMENT CORE REPAIR**

STANDARD PLAN
MVSI-132D-1

SHEET 4 OF 6